

1. PASS THE END MOUNT TABS THROUGH THE END CAP SLOTS, ASSEMBLING THEM AS SHOWN BELOW.
2. SLIP THE END MOUNT TABS INTO THE TRACK END, AND MAKE SURE THE END MOUNT OR ASSEMBLY IS PUSHED DIRECTLY AGAINST THE RACEWAY BASE END.
3. INSTALL SUPPLIED SCREWS INTO THE END MOUNT TAB TAPS, AND TIGHTEN THEM TO SECURELY CAPTURE END MOUNT/ASSEMBLY.

