




- Be careful not to leave this product at more than 60 degrees Celsius for a long time. Or it may not work properly due to deformation.
- This is a disposable product and the cleaning tape is not replaceable. Please properly dispose of it after the cleaning tape is running short.

1. Structure



2. How to Use



(1) Take up the winding reel until the new cleaning tape appears in the window in the direction of an arrow as shown in the photo A.



(2) Slide a connector while pressing its ferrule end-face against the tape in the direction of an arrow as shown in photo B.

(3) Keep the cassette with the used cleaning tape in the window after use. Make sure to keep up the winding reel until the new cleaning tape appears before every cleaning.

(4) If the cleaning tape is running out, please properly dispose of the cassette.

Senko Advanced Components, Inc.

Americas

USA EAST +1-888-32-SENKO
USA WEST +1-858-623-3300
TEXAS +1-972-661-9080
Sales-Americas@senko.com
BRAZIL: +55 -21-3736-7065
Sales-Brazil@senko.com

Asia

HONG KONG +852-2121-0516
SHANGHAI +86-21-5830-4513
SHENZHEN +86-755-2533-4893
Sales-Asia@senko.com

Europe

UK +44 (0) 1256 700880
ITALY +39 011 839 9828
POLAND +48-71 345-90-05
Sales-Europe@senko.com

Middle East - North Africa

DUBAI +971 4 8865160
Sales-MENA@senko.com

www.senko.com

Produced by NTT-AT

Asia Pacific

AUSTRALIA
+61 (0) 3 9755-7922
Sales-Asia-Pacific@senko.com

Japan

TOKYO
+81 (0)3 5825-0911
Sales-Japan@senko.com